


SEATING PLAN
Hamer Hall - Balcony




TOTAL STANDARD SEATING = 793
(INCLUDES 14 REMOVABLE SEATS PROVIDING 8 WHEELCHAIR POSITIONS)

SEATING PLAN
Hamer Hall - Circle



DOOR 6
ENTRY AND EXIT


DOOR 5
ENTRY AND EXIT



- SWING-ARM ACCESSIBLE SEAT
- REMOVABLE SEAT FOR
WHEELCHAIR POSITION
- COMPANION SEAT/
SWING-ARM ACCESSIBLE SEAT
- TECHNICAL OPTIONAL SEAT/
SWING-ARM ACCESSIBLE SEAT

TOTAL STANDARD SEATING = 559
(INCLUDES 10 REMOVABLE SEATS PROVIDING 6 WHEELCHAIR POSITIONS)
TOTAL (INC. CHOIR SIDE) SEATING = 631

SEATING PLAN
Hamer Hall - Stalls



- SWING-ARM ACCESSIBLE SEAT
- REMOVABLE SEAT FOR WHEELCHAIR POSITION
- COMPANION SEAT/ SWING-ARM ACCESSIBLE SEAT
- TECHNICAL OPTIONAL SEAT/ SWING-ARM ACCESSIBLE SEAT

TOTAL STANDARD SEATING = 969
(INCLUDES 24 REMOVABLE SEATS PROVIDING 16 WHEELCHAIR POSITIONS)
TOTAL (INC. ORCHESTRA PIT) SEATING = 1046